





DLP Projector Quick Start Guide


1



2




3






DLP Projector Quick Start Guide

4



5



6



<http://www.viewsonic.com/support/>

中国
http://www.viewsonic.com.cn
电话: 4008 988 588
香港
http://www.hk.viewsonic.com
電話: 852 3102 2900
澳門
http://www.hk.viewsonic.com
電話: 853 2870 0303
台灣
http://www.viewsonic.com.tw
電話: 0800 061 198
Korea
http://www.kr.viewsonic.com
Phone: 080 333 2131

Singapore/Malaysia/Thailand
http://www.ap.viewsonic.com
Phone: 65 6461 6044
India
http://www.in.viewsonic.com
Phone: 1800 266 0101
United States
http://www.viewsonic.com
Phone: 1-800-688-6688 (Toll-Free)
1-424-233-2530 (Toll)
Canada
http://www.viewsonic.com
Phone: 1-866-463-4775 (Toll-Free)
1-424-233-2533 (Toll)

Europe
http://www.viewsoniceurope.com
Australia/New Zealand
http://www.viewsonic.com.au
Phone: 1800 880 818 (AUS)
0800 008 822 (NZ)
South Africa
http://www.viewsonic.com
Latin America (Chile)
http://www.viewsonic.com/la/
Phone: 1230-020-7975
Latin America (Mexico)
http://www.viewsonic.com/la/
Phone: 001-8882328722

Latin America (Peru)
http://www.viewsonic.com/la/
Phone: 0800-54565
Latin America (Argentina)
http://www.viewsonic.com/la/
Phone: 0800-4441185
Puerto Rico & Virgin Islands
http://www.viewsonic.com
Phone: 1-800-688-6688 (English)
1-866-379-1304 (Español)